

Grundig Freeview High Definition Digital Set Top Box – GSTB4101FVE Software Upgrade via USB Instruction Guide

A software upgrade is available for the GSTB4101FVE that improves tuner sensitivity and the performance of the Freeview EPG.

Software Upgrade Steps:

- (1) Please ensure your USB has been formatted. Connect a USB stick to your computer and once connected right click on the USB icon and select the format option. Please note that this will clear the USB of all files currently on the USB.
- (2) Save the file **Freeview Sensitivity Software V0.30.bin** to the USB device (Please Note: save the file straight to the USB, do not place in any folders).
- (3) Once saved, plug the USB device into the USB Input on the back of the GSTB4104FVE. Detailed instructions for how to perform a software upgrade are located on page 18 of the instruction book.
- (4) Allow 10 seconds and then select the Software Update >Check for New Software Version from the Main Menu. The Set Top Box will search for the new Software version.
- (5) Once the new Software is located (V.30) you will be advised that a new software version has been found, select Download and install now.
- (6) When the download is complete, you will be advised that the upgrade is complete.
- (7) Once the set top box has returned to normal TV viewing, remove the USB, and perform a Factory Reset. This may be conducted by selecting First Time Install>Restore all settings to default.
- (8) Follow the prompts once the unit resets, and as a part of this you will perform an automatic channel scan.
- (9) You are now ready to resume operation of the box.

